



Plant sap sampling guide

Forage



Contact details

NovaCropControl
Nijverheidsweg 30
5061 KL Oisterwijk
The Netherlands
info@novacropcontrol.nl
www.novacropcontrol.nl



Collecting and submitting samples

Location

Take the following steps into consideration when collecting leaf samples:

- Avoid the outer rows of the field and the first and last 10 yards of a row.
- Sample leaves of average leaf quality.
- Sample abnormal plants (with deficiency symptoms) separately. If a deficiency might be present in the young or old leaves of the total crop, sample these leaves separately as a young or old leaf sample.
- Keep in mind the sunny and shady side of the plant. Always consistently sample the same side.

Time of sampling

It is strongly recommended to take the samples before 9:00 AM. The plant will then have enough leaf-tension with proper moisture conditions.

It is recommended to sample just before a cut or grazing, so that the fertilization for the new cut can be adjusted. For intensive monitoring it is recommended to sample twice per cut.

Plant parts

For a grass sample, cut the grass just above the root and keep in mind to sample such an amount so the sample bag is fully filled and the sample has enough mass (see pic. 2 and 3).

It is not allowed to send in samples that have a fungal, bacterial or virus infection. The leaves must also be free from insects.





Pic. 1



Pic. 2

Sample size

For an average, representative sample we need a sample bag filled for $\frac{3}{4}$. Of course sample size can vary, depending on leaf type (size and thickness). If you are unsure about the sample size, please feel free to contact us.





Packing the grass

When the grass is wet on the outside due to dew or rain, they can be dried with a tissue. Leaves have to be dry from the outside to be analyzed because water will have an influence on the results. Moreover, the leaves will spoil faster if there is water in the sample bag.

Make sure all air is out, so any leaf evaporation is excluded. See pictures.



Fill in the labels correctly and place them on the bags (see pictures below). We prefer pre-printed labels because it saves us a lot of administration time. It has also advantages for you:

- When using Bemesting-Online program you need the same location names and crop names to make comparisons (graphs), pre-printed labels make this a lot easier;
- If our employees must read what is on the label, the chance of reading errors is very high, this is not the case with preprinted labels;
- You no longer must write the location and crop name on the label on the spot.

Let us know if you need help with this.





Sending the samples

The leaf samples in zip-lock bags with barcode can be send in a box. Make sure you put all samples in one package so it will all arrive at the same time. In case you want to send one or two samples, you can put them in an envelope. Put sufficient postage on the envelope or package. Always check the weight. Please take care that envelopes and bags are sealed well. You can put an extra tape over the closure to avoid opening during transit.

Do you ship samples from outside Europe? To avoid clearance delay at the customs and high costs please consult our shipment guide for sending samples to Europe. You can find this guide at our website.

Please send samples to the address below:

NovaCropControl

Street: Nijverheidsweg 30

Zip-code: 5061 KL

Town: Oisterwijk

Country: The Netherlands

