



# ***General sampling guide***



## **Contact details**

NovaCropControl  
Nijverheidsweg 30  
5061 KL Oisterwijk  
The Netherlands  
013-590 2864  
info@novacropcontrol.nl  
[www.novacropcontrol.nl](http://www.novacropcontrol.nl)



## ***Collecting and submitting samples***

### **Location**

Take the following steps into consideration when collecting leaf samples:

- Avoid the outer rows of the field and the first and last 10 yards of a row.
- Sample leaves of average leaf quality.
- Sample abnormal plants (with deficiency symptoms) separately. If a deficiency might be present in the young or old leaves of the total crop, sample these leaves separately as a young or old leaf sample.
- Keep in mind the sunny and shady side of the plant. Always consistently sample the same side.

### **Time of sampling**

It is strongly recommended to take the samples before 9:00 AM. The plant will then have enough leaf-tension with proper moisture conditions.

### **Plant parts**

For sampling, take the **youngest, fully developed leaf**. Also take the **oldest, vital leaf**. Please remove the petioles from the leaf. These petioles can have a significant effect on the analysis of the leaf sample. So for the analysis you will have an old leaf sample and a young leaf sample. It is not allowed to send in samples that have a fungal, bacterial or virus infection. The leaves must also be free from insects.

### **Sample size**

In general 30 leaves should be enough for a complete analysis (30 young and 30 old leaves, at least 150 grams). This amount depends on type, size and shape of leaves. If you are unsure about the sample size, please feel free to contact us.





### Packing the leaf samples

When leaves are wet on the outside due to dew or rain, they can be dried with a tissue. Leaves have to be dry from the outside to be analysed because water will have an influence on the results. Moreover, the leaves will spoil faster if there is water in the sample bag.

Please pack the young and old leaf samples separately, these will be two different samples. To assure fluent processing please stack the leaves, fold the leaves if needed, and put them in a plastic zip-lock bag carefully. Make sure all air is out, so any leaf evaporation is excluded. See pictures.



Fill in the labels correctly and place them on the bags (see pictures below). We prefer pre-printed labels because it saves us a lot of administration time. It has also advantages for you:

- When using Bemesting-Online program you need the same location names and crop names to make comparisons (graphs), pre-printed labels make this a lot easier;
- If our employees must read what is on the label, the chance of reading errors is very high, this is not the case with preprinted labels;
- You no longer must write the location and crop name on the label on the spot.

Let us know if you need help with this.





## Sampling water

Make sure that the bottle is completely full. The analysis may be wrong if there are air bubbles in the bottle.



Take a drip water sample at the dripper like in the picture below. A slab water sample can be taken by a syringe out of the substrate bag. Make sure you take the samples from several substrate bags, see the picture below. A drain water sample can be taken from the water return system.



The labels for a water sample need to be placed in such a way that the barcode is still readable.



Tighten the cap enough so that it does not leak. Do not overtighten as this may break the cap.







### **Sending the samples**

The leaf samples in zip-lock bags with barcode can be send in a box. Make sure you put all samples in one package so it will all arrive at the same time. In case you want to send one or two samples, you can put them in an envelope. Put sufficient postage on the envelope or package. Always check the weight. Please take care that envelopes and bags are sealed well. You can put an extra tape over the closure to avoid opening during transit.

Do you ship samples from outside Europe? To avoid clearance delay at the customs and high costs please consult our shipment guide for sending samples to Europe. You can find this guide at our website.

Please send samples to the address below:

### **NovaCropControl**

Street: Nijverheidsweg 30

Zip-code: 5061 KL

Town: Oisterwijk

Country: The Netherlands

