

Plant sap sampling guide

Kohlrabi



Contact details

NovaCropControl
Nijverheidsweg 30
5061 KL Oisterwijk
The Netherlands
Tel: +3113-5902864
info@novacropcontrol.nl
www.novacropcontrol.nl



Collecting and submitting samples

Location

Take the following steps into consideration when collecting leaf samples:

- Avoid the outer rows of the field and the first and last 10 yards of a row.
- Sample leaves of average leaf quality.
- Sample abnormal plants (with deficiency symptoms) separately. If a deficiency might be present in the young or old leaves of the total crop, sample these leaves separately as a young or old leaf sample.
- Keep in mind the sunny and shady side of the plant. Always consistently sample the same side.

Time of sampling

It is strongly recommended to take the samples before 9:00 AM. The plant will then have enough leaf-tension with proper moisture conditions.

Begin with analyzing from 5th leaf stage, every three weeks until harvest (3 to 4 times).

Part of the plant

For sampling, pick the **youngest, fully developed, representative leaf** counting from the centre of the plant to the outside. Also pick the **oldest, vital, representative leaf** at the outside of the plant (closer to the ground), see pic. 1+2.



Remove the petioles from the leaf. Petioles can have a significant effect on the analysis of the leaf sample. For the analysis you will have a separate young leaf sample and an old leaf sample. Please cut off the petiole at the point where the leaf dish starts (red line at the picture on the left).

It is not allowed to send in samples that have a fungal, bacterial or virus infection. The leaves must also be free from insects.





Pic. 1+2



Young,
fully
developed
inner leaf

Old, vital
leaf at the
base of the
plant



Young,
fully
developed
inner leaf

Old, vital
leaf at the
base of the
plant





Sample size

For an average, representative sample about 20 leaves are needed, 150 grams should be enough. Sample size can vary depending on leaf type (size and thickness). If you have questions about sample size, please contact us.

Packing the leaf samples

When leaves are wet on the outside due to dew or rain, they can be dried with a tissue. Leaves have to be dry from the outside to be analyzed because water will have an influence on the results. Moreover, the leaves will spoil faster if there is water in the sample bag. Please pack the young and old leaf samples separately, these will be two different samples. To assure fluent processing please stack the leaves, fold the leaves if needed, and put them in a plastic zip-lock bag carefully. Make sure all air is out, so any leaf evaporation is excluded.



Fill in the labels correctly and place them on the bags (see pictures below). We prefer pre-printed labels because it saves us a lot of administration time. It has also advantages for you:

- When using Bemesting-Online program you need the same location names and crop names to make comparisons (graphs), pre-printed labels make this a lot easier;
- If our employees must read what is on the label, the chance of reading errors is very high, this is not the case with preprinted labels;
- You no longer must write the location and crop name on the label on the spot.

Let us know if you need help with this.





Sending the samples

The leaf samples in zip-lock bags with barcode can be send in a box. Make sure you put all samples in one package so it will all arrive at the same time. In case you want to send one or two samples, you can put them in an envelope. Put sufficient postage on the envelope or package. Always check the weight. Please take care that envelopes and bags are sealed well. You can put an extra tape over the closure to avoid opening during transit.

Do you ship samples from outside Europe? To avoid clearance delay at the customs and high costs please consult our shipment guide for sending samples to Europe. You can find this guide at our website.

Please send samples to the address below:

NovaCropControl

Street: Nijverheidsweg 30

Zip-code: 5061 KL

Town: Oisterwijk

Country: The Netherlands

